



Spire Software Upgrade instructions

To complete a software upgrade on your terminal, please follow the simple steps below


- 1 Press the red cancel button at the bottom of the key-pad to access the 'Enter amount' screen




- 5 Press the Main Menu button (square button below the terminal screen)




- 2 Press the Main Menu button (square button below the terminal screen)




- 6 Press right arrow (underneath the screen) and select 'Function'



- 3 Select 'Batch' followed by 'Settle/end of day'



- 7 Type in 92 and press the green Enter' button.




- 4 Type in '4-digit password' (the default - '0000') and press green enter button. The terminal will now connect to the Acquirer.



Once finished the terminal will print out a receipt and is now ready to complete the software upgrade

- 8 Type in '4-digit password' (the default - '0000') and press green enter button. Press the green 'Enter' button accept 'Prog.-Load. correct?' message:



The terminal will now connect to the Spire Terminal Management system to complete an update. On your screen you should see the message, download in progress and a % counter. Once the upgrade reaches 100% the terminal will automatically restart back to the 'Enter Amount' screen and print a successful upgrade receipt.

For further support please contact your technical helpdesk.